

Flexi-Beams™ Prices from 2019



Two beams in Steel each with 2 x 1 tonne load cells, with 5 metre signal cables

- Length 850 mm, per pair £680.00 GBP
- Length 1000 mm, per pair £740.00 GBP
- Length 1200 mm, per pair £800.00 GBP

Indicator calibrated to 3 tonnes x 1 kg, with 12 volt power cable

- WT1-Standard Indicator shows weight on scale £385.00 GBP
- WT3-Indicator with total memory £485.00 GBP
- WH1-Indicator with set point for batch weighing £635.00 GBP

Accessories

- Tally roll desk top printer £440.00 GBP
- Tally roll external printer in weatherproof housing £560.00 GBP

Griffith Elder and Company Ltd

1 Oaklands Park
Bury St Edmunds
Suffolk
IP33 2RW
United Kingdom

+44 1284 763616
sales@griffith-elder.com
www.griffith-elder.com

Delivery (destination dependant) From £30 to £500 GBP

All indicators are low voltage and run from 12 volts DC.

Prices above do not include VAT, local taxes or import duties.

Flexi-Beams™

Accurate Portable Scales



The Flexi-Beams™ provide a rugged portable weighing system which can be used in many commercial applications.

Simple to Operate

In operation the system is simple. To use the **Flexi-Beams™** all the operator has to do is to switch the weigher on. If there is a weight showing on the display while nothing is on the beams then they can be zeroed by pressing the zero key on the indicator. The beams have been factory calibrated for maximum accuracy, and have been designed to maintain a high level of accuracy while being used on both level and uneven ground. No special setting up is needed, just drop them on the floor and plug them in.

The **Flexi-Beams™** can be set at any distance apart for weighing a wide range of commodities such as pallets and boxes, even scenery for television studios or steel girders.

Weigh Sensors

The Flexi-Beams™ have weight sensors built into them which are both waterproof and very robust. Each Flexi-Beam™ can take a weight of up to 2000 kilograms giving an overall maximum capacity of 4000 kilograms on a pair. Up to four beams may be used together on one indicator. If a platform is fitted to the beams, this can be zeroed out so that the indicator only shows the load weight. Damping can be put into the sensors so that the beams can be put under a cage to weigh animals.

Indicators

All the Griffith Elder range of Brain Box indicators can be used with the Flexi-Beams™, from a simple indicator which can be run from a 12 volt battery, or a wall mounted printer, to a batch weight controller which can have up to eight set points. An adaptor is available for running the Flexi-Beams™ from the mains electricity.